





# Kit 1458

FORD Fusion, 5-dr Hatchback, 06–  
FORD Figo, 5-dr Hatchback, 10–



480R  
754











480




750




**Kit**




**3**



754




750




**1**

X

**2**




	X
FORD Fusion, 5-dr Hatchback, 06-	35,5
FORD Figo, 5-dr Hatchback, 10-	33,5



**1**

Y

**2**




	Y
FORD Fusion, 5-dr Hatchback, 06-	32,5
FORD Figo, 5-dr Hatchback, 10-	29,5




480R



480




**1**




X inch/mm


**2**



	X inch	X mm
FORD Fusion, 5-dr Hatchback, 06-	39 <sup>5</sup> / <sub>8</sub> "	1006 mm
FORD Figo, 5-dr Hatchback, 10-	38 <sup>7</sup> / <sub>8</sub> "	986 mm




**1**



Y inch/mm


**2**










	Y inch	Y mm
FORD Fusion, 5-dr Hatchback, 06-	38 <sup>3</sup> / <sub>8</sub> "	976 mm
FORD Figo, 5-dr Hatchback, 10-	37 <sup>1</sup> / <sub>4</sub> "	946 mm

4


FORD Fusion, 5-dr Hatchback, 06-






FORD Figo, 5-dr Hatchback, 10-



5



	X mm	Y mm	X inch	Y inch
FORD Fusion, 5-dr Hatchback, 06–	300 mm	700 mm	11 3/4"	27 1/2"
FORD Figo, 5-dr Hatchback, 10–	300 mm	700 mm	11 3/4"	27 1/2"



**GB/US** Tighten alternately

**D** Die Schrauben abwechselnd anziehen

**F** Serrer alternativement chaque côté

**NL** Afwisselend aan de linker- en de rechterkant aandraaien

**I** Alternare il serraggio delle viti

**E** Apertar alternativamente

**PT** Aperte alternadamente

**S** Dra åt växelvis

**FIN** Kierrä vuorotellen

**EST** Pinguldage vaheldumisi

**LAT** Pielieciet pamišus

**LIT** Užsukinėkite pakaitomis

**PL** Śruby dokręcaj naprzemiennie

**RU** Затягивайте попеременно

**CZ** Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.

**SK** Doťahujte striedavo

**SLO** Privijajte izmenično.

**HR** Naizmjenično zategnite

**HU** Egymástól függetlenül szorítandó

**GR** Σφιγγετε εναλλάξ

**TR** Dönüşümlü sıkın


**中文** 交替拧紧

**한국어** 번갈아 가며 조이십시오.

**日本語** 交互に締め付けてください。

**ไทย** ชันในแบบสลับ



6




480R/754




480





\*  
3 Nm




\*




\*  
≈ 3 Nm



750










4 Nm








7




x1  
17 mm






**THULE**  
SWEDEN  
**ONE  
KEY  
SYSTEM**



- 544 (x4)
- 596 (x6)
- 588 (x8)
- NA 510 (x10)
- EUR 452 (x12)
- ASIA



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN  
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com  
customer.service@thule.com

www.thule.com